

Screen Removal & Installation

Ortal Stand Alone (Front Facing)



Photo showing screen installed.



Step 1: Remove side trim pieces by pulling them away from the fireplace. This trim is secured by magnets that stick to the vertical profile surface.



Step 2: Handling the mesh by the frame, push the mesh towards the fireplace glass. It is secured by magnets to the face of the fireplace housing.



Step 3: Lift the mesh up until the bottom of the framed mesh is over the lower lip of the opening.



Step 4: Lower and guide the mesh out of the fireplace opening.



Note: Magnets need to be extended approximately 3/8" for proper spacing.

***Repeat steps 1-4 in reverse order to install the mesh.**