
Framing Information: 44HH Corner (RS/LS) (Screen & Double Glass)



Framing Dimensions




Model	А	В	С	D
44HH RS/LS	49 ½"	48 ¹⁵ / ₁₆ "	21 %"	Refer to Vent Manufacturer's Firestop Dimensions

Note: 1. Drawings are not to Scale

2. All dimensions in inches

3. No weight can be transferred to the fireplace. ALL FRAMING MUST BE SELF-SUPPORTED.

Framing Information: 44HH Corner (RS/LS) (Screen & Double Glass) POUR LIFE. YOUR FIRE Framing Details Noting langes fed up and cornect to the framing. ALL FRAMING MUST BE SELF-SUPPORTED. The fireplace must not bear any weight. Heat Release Framing Exterior Framing Exterior Framing Exterior Framing Exterior Framing Exterior



Elevation View

Top View

The valve can be moved 36" from the center of the fireplace in any direction

Section View

(required for double glass only)

Note: 1. Drawings are not to Scale

Add drywall nailer as needed.


- 2. All dimensions in inches
- 3. No weight can be transferred to the fireplace. ALL FRAMING MUST BE SELF-SUPPORTED.

Page 2 of 3


Framing Information: 44HH Corner (RS/LS) (Screen & Double Glass)




Fireplace Dimensions



Front View



Top View



Protective Cover for double glass fans. Ships on double glass models only

Model	(H) (Height V	(W)	(D)	C1	C2	C3	Viewing Area	
Wodel		Width	Depth				Front	Side
44HH RS/LS	49 ½"	48 ¹⁵ ⁄ ₁₆ "	21 %"	7 %"	24 ¹² / ₄₀ "	12 ⁵ / ₆ "	44 ¹³ / ₁₆ " W X 29 ½" H	14 ¹³ %。" W X 29 %" H
4411111X3/L3	10 / 2	10 /16	2.70	' /0	- 1 / 10	12 /10	11 716 11 7 20 72 11	11 716 11 7 20 72 11

Note: 1. Drawings are not to Scale

2. All dimensions in inches

Page 3 of 3