





## Quanix removal guide




Quanix holder



Side trim



Quanix



Front trim



(M6)Screw

## 1.Removing the sides trim :

1a. Using your index finger pull the upper side of the profile until it releases from the magnets, then remove it , (as shown in figure (1)).

1b. Remove the other side trim in the same manner.




figure (1)

## 2.Removing the front trim :

2a. Use a screwdriver to remove the two screws from each side of the trim , (as shown in figure (2)).



figure (2)

2b. Lift the trim from the side, and remove it , (as shown in figure(3)).




figure (3)

## 3. Removing the quanix :

3a. Using your hand push the quanix holder from the middle to release the quanix ,  
(as shown in figure (4)).




figure (4)

3b. while holding the quanix up pull the bottom of the qunix by the other hand until it clear the frame,  
(as shown in figure (5)).




figure (5)

3c. pull the quanix down and out , and remove,  
(as shown in figure (6)).




figure (6)