
Framing Information: 77 Corner (RS/LS) (Screen & Double Glass)



Framing Dimensions



Model	А	В	С	D	
77 RS/LS	35 ¾"	84 ¹³ ⁄ ₁₆ "	21 %"	Refer to Vent Manufacturer's Firestop Dimensions	

Note: 1. Drawings are not to Scale

2. All dimensions in inches

3. No weight can be transferred to the fireplace. ALL FRAMING MUST BE SELF-SUPPORTED.

Framing Information: 77 Corner (RS/LS) (Screen & Double Glass) YOUR LIFE. YOUR FIRE Framing Details Nailing flanges fold up and connect to the framing. ALL FRAMING MUST BE SELF-SUPPORTED. The fireplace must not bear any weight. Heat Release Heat Release -5/8" Type X Drywall on Framing Exterior 5/8" Type X Drywall on Framing Exterior Combustible Framing Air Intake (required for double glass only) Add drywall nailer as needed. Section View Elevation View Top View The valve can be moved 36" from the center of the fireplace in any direction

Note: 1. Drawings are not to Scale

2. All dimensions in inches


3. No weight can be transferred to the fireplace. ALL FRAMING MUST BE SELF-SUPPORTED.

Page 2 of 3

Framing Information: 77 Corner (RS/LS) (Screen & Double Glass)



Fireplace Dimensions



Model	(H)	(W)	(D)	C1	C2	C2 C3			g Area
Wiodei	Height	Width	Depth	0'	02		Front	Side	
77 RS/LS	35 ¾"	84 ¹³ / ₁₆ "	21 %"	7 %"	41 %"	12 ½"	78 ¾" W X 15 ¾" H	14 ¹³ % ₆ " W X 15 ¾" H	

Note: 1. Drawings are not to Scale

2. All dimensions in inches